

保存版

KLR250

Motorcycle Owner's Manual



(Australian model only)

TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED

Owners are warned that the law may prohibit:

- (a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- (b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.



Whenever you see the symbols shown below, heed their instructions! Always follow safe operating and maintenance practices.

This warning symbol identifies special instructions or pro-WARNING cedures which, if not correctly followed, could result in personal injury, or loss of life.

This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

"Note" indicates points of particular interest for more efficient and convenient operation.

NOTICE

THIS PRODUCT HAS BEEN MANUFAC-TURED FOR USE IN A REASONABLE AND PRUDENT MANNER BY A QUALI-FIED OPERATOR AND AS A VEHICLE ONLY.



FOREWORD

We wish to thank you for choosing this fine Kawasaki Motorcycle. Your new motorcycle is the product of Kawasaki's advanced engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Read this Owner's Manual before riding so you will be thoroughly familiar with the proper operation of your motorcycle's controls, its features, capabilities and limitations. This manual offers many safe riding tips, but its purpose is not to provide instruction in all the techniques and skills required to ride a motorcycle safely. Kawasaki strongly recommends that all operators of this vehicle enroll in a motorcycle rider training program to attain awareness of the mental and physical requirements necessary for safe motorcycle operation.

To ensure a long, trouble-free life for your motorcycle, give it the proper care and maintenance described in this manual. For those who would like more detailed information on their Kawasaki Motorcycle, a Service Manual is available for purchase from any Kawasaki Dealer. The Service Manual contains detailed disassembly and maintenance information.

Due to improvements in design and performance during production, in some cases there may be minor discrepancies between the actual vehicle and the illustrations and text in this manual.

KAWASAKI HEAVY INDUSTRIES, LTD. Consumer Products & Machinery Group

..... TABLE OF CONTENTS

pecifications										4
ocation of Parts					**	or.				7
eneral Information						*				10
Meter Instruments	12				*		Ä.			10
Speedometer and										
Tachometer					¥.		÷		÷	11
Water Temperature	0	àa	ug	e		į.	÷			11
Indicator Lights .			(*)						50	11
Key				×	٠		٠		×	12
Ignition Switch/										
Steering Lock .	002	2			4	ř	į,	į.		12
Left Handlebar Switch										
Dimmer Switch	0.00	*	*	i	,					13
Turn Signal Switch	١.		*	*	100		(*)			13
Horn Button				*						13
Headlight Switch	24		ij.	Ŷ		è				13
Engine Stop Switch.		0	14	Š	ij,	ž		·	÷	14
Fuel Tank Cap			,							14
Fuel Tank				7	or or					15
Fuel Tap		· ·			: ·					16
Stand						2				17

Steering Lock			*	***	×	**			18
Helmet Hook									19
Document/Tool Kit Bag		4	į,					ě	19
Tool Kit								÷	19
reak-In · · · · · · · ·						·		ï	20
low to Ride the Motorcycl	e								21
Starting the Engine	12		į.	i				÷	21
Moving Off		į.	į.				÷		24
Shifting Gears						•			25
Braking			100	 **	•				25
Stopping the Engine	2								26
Stopping the Motorcycl									
in an Emergency		3					72	ø	26
Parking	2	ď.	3	æ				Ĺ	27
Safe Operation		167		ii.		linn Tu	i di Ta		28
Daily Safety Checks				ato pro		100	ez ez	-	28
Additional Consideration					•			•	
Off Road Operation					•	٠		٠	30

Maintenance and A	d	ju	st	m	e	nt			100					31
Periodic Mainte	na	an	CE	9 (Ch	nai	rt							32
Engine Oil				8								į.		35
Cooling System				÷		2								38
Spark Plug	i i			į				÷						44
Valve Clearance			·		er.				•		4	-	v	46
Air Cleaner														
Throttle Grip .														
Choke Lever						Ċ.	Ē.	į.	ò		Ē	e.	Ē	50
Carburetor	38			100	10.	37		1	0	10		1	-	51
Clutch		*		100	•			9			*1			52
Drive Chain					ovo					38	e e	v.		54
Brakes														
Brake Light Swi	tc	h	es			a.				÷	÷			64
Front Fork		•		٠					Ÿ		÷			65
Rear Shock Abs	01	rb	er								**			66
Wheels		*	90		*					 		•		69
Battery														
Headlight Beam	¥.	ķ.				S.		ş	÷		1			73
Fuses	·	ċ				į.			ş:		i			75
Fuel System		è.		'n.	ř.	4								76
Cleaning	100						**		**			*0		77

Storage						é								79
Wiring Diagram	à	4	è	è	1	n	sic	de	b	a	ck	(0	ver